






DEEP SEATING ARM INSTRUCTIONS



Club Chair



Love Seat



Sofa

COMPONENTS

DSARM Box

Contains:

- Left Arm
- Right Arm
- 2 Arm Spacers
- 2 Seat Angles
- Hardware Pack

DSMOD Boxes

Contains:

- Chair Back
- Chair Seat

Note: (1) box for Club Chair
(2) boxes for Love Seat
(3) boxes for Sofa


HARDWARE PACK

- (10) 3" Bolts
- (2) 1.5" Bolts
- (12) Barrel Nuts
- (4) 2.5" Plugs
- (1) Allen Wrench

SUGGESTED TOOLS

- PHILLIPS HEAD SCREWDRIVER

Use ruler to find correct bolt size.




Tip: When using a barrel bolt with a barrel nut, place the bolt into the barrel nut and gently turn it counter clockwise until you feel a slight click. Then proceed to turn the bolt clockwise to tighten the barrel nut onto the barrel bolt.

STEP 1. Using (5) 3" Bolts, (1) 1.5" Bolt, (2) 2.5" Plugs, and (6) Barrel Nuts attach the Right Arm to the Seat Back with the Arm Spacer and the Chair Seat with the Seat Angle. **Assembly works best when Plugs are used first.**

For Club Chair: Repeat for Left Arm then tighten bolts and enjoy!

For Sofa and Love Seat: Repeat for left arm using the back and seat from a separate DSMOD box. Keep all hardware loose until finishing Center Leg assembly, refer to instructions in Center Leg box.

Club Chair shown below.



Congratulations on purchasing this Deep Seating Furniture. QUESTIONS REGARDING THIS PRODUCT? Call our customer service team, 252-758-0641.

RESIDENTIAL WARRANTY - This quality product includes a LIMITED LIFETIME WARRANTY for RESIDENTIAL CUSTOMERS. In the unlikely event any splintering, rotting, cracking, peeling, or chipping should ever occur, The Hammock Source will supply replacement parts or replace the furniture, at no charge to you. This does not include negligence, improper use, animal damage or damage caused by natural disasters. When using around fire, keep furniture at a minimum distance of 30 inches from the heat source. Prevent prolonged exposure to chlorinated water. Note that an original sales receipt must accompany any returned product, along with a Return Authorization Number from Hammock Source customer service; call at 252-758-0641.

CONTRACTOR WARRANTY - CONTRACTORS receive a LIMITED 7-YEAR WARRANTY. Follow the same steps outlined above.

MAINTENANCE - Thoroughly inspect product before each use. Periodically check bolts after assembly and re-tighten when necessary.

