



DEEP SEATING CENTER LEG INSTRUCTIONS



Love Seat



Sofa

COMPONENTS

DSCTL Box

Contains:

- Center Leg Front
- Center Leg Rear
- Center Leg Spreader
- Hardware Pack

Note: (1) box for Love Seat
(2) boxes for Sofa


HARDWARE PACK

- (6) 3" Bolts
- (6) Barrel Nuts
- (2) 2.5" Plugs
- (2) 2" Torx Screws
- (1) Long Torx Head Bit

SUGGESTED TOOLS

- SOCKET WRENCH
- 7/16" x 1/4" DEEP SOCKET
- PHILLIPS HEAD SCREWDRIVER

Use ruler to find correct bolt size.




Tip: When using a barrel bolt with a barrel nut, place the bolt into the barrel nut and gently turn it counter clockwise until you feel a slight click. Then proceed to turn the bolt clockwise to tighten the barrel nut onto the barrel bolt.

ASSEMBLY

STEP 1. Put Center Leg Spreader into the front and rear center legs. Use the (2) 2" Torx Screws to attach them together and tighten the screws.

NOTE: BEGIN DSARM ASSEMBLY BEFORE STARTING STEP 2




STEP 2. Use (6) 3" Bolts, (6) Barrel Nuts, and (2) 2.5" Plugs to attach Right Arm Assembly to Center Frame Leg.

Note: For the Love Seat use the Right and Left Arm Assemblies prepared through the DSARM instructions.

Tighten all hardware and enjoy!


For the Sofa use the Right Arm Assembly and the unused DSMOD Seat and Back, leave the Left Arm Assembly aside for step 3.

Keep all Hardware loose until Step 3.



STEP 3. Repeat Step 1 and 2 with second Center Leg Box.

Following the same process in step 2, attach Left Arm Assembly to the assembly made in step 2 with the Arm Spacer and Seat Angle. **Tighten all Hardware and enjoy!**



Congratulations on purchasing this Deep Seating Furniture. QUESTIONS REGARDING THIS PRODUCT? Call our customer service team, 252-758-0641.

RESIDENTIAL WARRANTY - This quality product includes a LIMITED LIFETIME WARRANTY for RESIDENTIAL CUSTOMERS. In the unlikely event any splintering, rotting, cracking, peeling, or chipping should ever occur, The Hammock Source will supply replacement parts or replace the furniture, at no charge to you. This does not include negligence, improper use, animal damage or damage caused by natural disasters. When using around fire, keep furniture at a minimum distance of 30 inches from the heat source. Prevent prolonged exposure to chlorinated water. Note that an original sales receipt must accompany any returned product, along with a Return Authorization Number from Hammock Source customer service; call at 252-758-0641.

CONTRACTOR WARRANTY - CONTRACTORS receive a LIMITED 7-YEAR WARRANTY. Follow the same steps outlined above.

MAINTENANCE - Thoroughly inspect product before each use. Periodically check bolts after assembly and re-tighten when necessary.

