



ESSENTIALS/SUNRISE DINING CHAIR WITH ARMS INSTRUCTIONS

Sunrise chair back different than shown.




ASSEMBLY

STEP 1. Use (6) 1.5" barrel bolts to attach chair back to chair seat. **Keep all barrel bolts loose until Step 4.**



HARDWARE PACK



CHAIR PARTS

- CHAIR SEAT
- CHAIR BACK
- BOTTOM CHAIR FRAME
- LEFT ARM/LEG ASSEMBLY
- RIGHT ARM/LEG ASSEMBLY


SUGGESTED TOOLS

- PHILLIPS HEAD SCREWDRIVER


Tip: When using a barrel bolt with a barrel nut, place the bolt into the barrel nut and gently turn it counter clockwise until you feel a slight click. Then proceed to turn the bolt clockwise to tighten the barrel nut onto the barrel bolt.

ASSEMBLY


STEP 2. Use (4) 1.5" barrel bolts and (4) barrel nuts to attach left & right arm/leg assemblies to chair seat. **Keep all barrel bolts loose until Step 4.**



STEP 3. Use (2) 1.5" barrel bolts and (2) barrel nuts to attached left & right arm/leg assemblies to chair back. **Keep all barrel bolts loose until Step 4.**



STEP 4. Use (8) 1.5" barrel bolts and (8) barrel nuts to attach bottom chair frame to chair legs. **Tighten all bolts.**



Congratulations on purchasing this Durawood Essentials/Sunrise Dining Chair with Arms. QUESTIONS REGARDING THIS PRODUCT? Call our customer service team, 252-758-0641.

RESIDENTIAL WARRANTY - This quality product includes a LIMITED LIFETIME WARRANTY for RESIDENTIAL CUSTOMERS. In the unlikely event any splintering, rotting, cracking, peeling, or chipping should ever occur, The Hammock Source will supply replacement parts or replace the furniture, at no charge to you. This does not include negligence, improper use, animal damage or damage caused by natural disasters. When using around fire, keep furniture at a minimum distance of 30 inches from the heat source. Prevent prolonged exposure to chlorinated water. Note that an original sales receipt must accompany any returned product, along with a Return Authorization Number from Hammock Source customer service; call at 252-758-0641.

CONTRACTOR WARRANTY - CONTRACTORS receive a LIMITED 7-YEAR WARRANTY. Follow the same steps outlined above.

MAINTENANCE - Thoroughly inspect product before each use. Periodically check bolts after assembly and re-tighten when necessary.

