



TRI-BEAM® ARC HAMMOCK STAND INSTRUCTIONS




HARDWARE PACK

(4) Bolt Assembly




(2) Offset Hook



Required Tools


- Adjustable Wrench

STAND PARTS




NOTE: TWO PERSON ASSEMBLY SUGGESTED

STEP 1. Lay all hammock stand parts on a flat surface.




ASSEMBLY

STEP 1. Connect a foot beam to an end beam using two of the provided bolt assemblies. **Tighten securely** with adjustable wrench. Repeat this step with the remaining foot and end beams.




STEP 2. Connect the center beam to an end beam, using the spring pin to secure the connection. **Ensure the spring pin is fully engaged.** Repeat this step on the opposite end.



STEP 3. Attach offset hooks to the end beams and hang hammock at a comfortable height.

NOTE: 'TOP' OF THE OFFSET HOOK SHOULD GO INTO THE END BEAM.



Congratulations on your purchase. QUESTIONS REGARDING THIS PRODUCT? Call our customer service team, 252-758-0641.

CAUTION:

Please inspect your stand before use and periodically during the usage season for tightness of fasteners, weld integrity, or excessive rust.

Use caution when lying in your hammock. Position your body in the center of the hammock and lower yourself gently. The hammock ropes will stretch with use and should be checked routinely. Hammock chain should be adjusted as needed.

- **DO NOT EXCEED LOAD LIMIT OF 450 LBS.**
- **DO NOT ALLOW INFANTS ON THE HAMMOCK.**
- **DO NOT ALLOW CHILDREN TO USE THE HAMMOCK WITHOUT DIRECT ADULT SUPERVISION.**
- **DO NOT REPLACE THE OFFSET HOOK WITH OTHER HARDWARE.** The offset hooks that come with your hammock are specifically selected to be strong enough for use with your hammock stand. If you need replacement offset hooks, please contact us at 252-758-0641.

WARRANTY INFORMATION:

Products of The Hammock Source are guaranteed to be free of defects in workmanship and materials for up to one year after the purchase date. Prolonged exposure to weather conditions including snow, rain, and humidity are not covered under the warranty nor is damage caused by negligence, normal wear, mildew, improper care including storage, maintenance, and installation. If an item is found to be defective within one year of its purchase, it will be replaced without charge upon the return of the unit accompanied by a sales receipt. A Return Authorization is needed for return and may be obtained by contacting 252-758-0641.